

# Updating Troubleshooting and Frequently Asked Questions

This document gives helps  
you when updating your drive  
and gives some answers to  
frequently asked questions.



Philips Consumer Electronics  
Version 12

# PHILIPS

### ***Which precautions should I take before updating?***

- Please close all running software applications.
- Temporarily disconnect from the Internet and shutdown antivirus programs.
- Eject any discs from the drive you want to update.
- As long as the updating process is ongoing, do not interact with the PC.
- Do not try to update with any version, which is not officially released by Philips.

### ***Do I loose my warranty when I update my drive?***

No, as long as you follow our precautions and as long as you only use official updates for your product.

### ***How long does updating take?***

Normally, it takes only a minute to update your drive.

It is possible that the updating tool requires a restart of your system before updating.

### ***Do I have to restart my system after updating?***

If required, the updating tool will ask you to restart (reboot) your system, to make sure your drive will work fine after updating.

### ***Windows™ says if found new hardware after updating. Is this correct?***

Yes, Windows™ may see your drive has been updated, and will therefore show the "New hardware found". This screen will disappear after some seconds..

### ***The update tool does not work or reports that the file was damaged***

The update tool checks itself before updating starts. If an error occurred during downloading the update file, this will be detected and the tool will refuse to work. Download the update file again.

### ***The update tool reported "Invalid firmware version" (or similar). What now?***

You probably selected the wrong update.

Go to [www.philips.com/storageupdates](http://www.philips.com/storageupdates) and choose install the Philips Intelligent Agent to receive automatically the correct downloads for your Philips drive.